

WINTER DRAINING DOWN

- 1. Turn water off outside (tap is outside underneath the caravan, beneath the kitchen window)**
- 2. Open the outside garden tap (between the steps and the plastic shed). Leave this open – this is the lowest point so drains down the whole caravan.**
- 3. Open all inside taps and leave open (taps should be set mid-way between hot and cold so that both hot and cold systems drain down)**
- 4. Disconnect shower hose and leave shower tap open to drain.**
- 5. Flush the toilet.**